Old Man Emu
Suspension Lift Kits
Quick Reference Guide

TACOMA KITS					
KIT	**DESC**	**VEHICLE**	**YEAR**	**PRICE**	**PAGE**
1003K	Nitrocharger Lift Kit Front 2"/ 0-330lbs. Rear 0"/ 0 lbs	TACOMA	2005-2015	$ 856.00	4
1004K	Nitrocharger Lift Kit Front 2"/ 0-330lbs. Rear 2"/ 0 lbs	TACOMA	2005-2015	$ 1,766.87	4
1005K	Nitrocharger Lift Kit Front 2"/ 0-330lbs. Rear 2"/ 660 lbs	TACOMA	2005-2015	$ 1,832.87	4
1103K	MT64 Lift Kit Front 2"/ 0-330lbs. Rear 0"/ 0 lbs	TACOMA	2005-2015	$ 1,854.00	5
1104K	MT64 Lift Kit Front 2"/ 0-330lbs. Rear 2"/ 0 lbs	TACOMA	2005-2015	$ 2,764.87	5
1105K	MT64 Lift Kit Front 2"/ 0-330lbs. Rear 2"/ 660 lbs	TACOMA	2005-2015	$ 2,830.87	5
1203K	BP51 Lift Kit Front 2"/ 0-330lbs. Rear 0"/ 0 lbs	TACOMA	2005-2023	$ 3,067.00	6
1204K	BP51 Lift Kit Front 2"/ 0-330lbs. Rear 2"/ 0 lbs	TACOMA	2005-2023	$ 3,977.87	6
1205K	BP51 Lift Kit Front 2"/ 0-330lbs. Rear 2"/ 660 lbs	TACOMA	2005-2023	$ 4,043.87	6
1006K	Nitrocharger Lift Kit Front 2"/ 0 lbs. Rear 0"/ 0 lbs	TACOMA	2016-2023	$ 856.00	7
1007K	Nitrocharger Lift Kit Front 2"/ 220-330lbs. Rear 0"/ 0 lbs	TACOMA	2016-2023	$ 856.00	7
1008K	Nitrocharger Lift Kit Front 2"/ 0 lbs. Rear 1.25"/ 0 lbs	TACOMA	2016-2023	$ 1,041.87	7
1009K	Nitrocharger Lift Kit Front 2"/ 220-330lbs. Rear 1.25"/ 0 lbs	TACOMA	2016-2023	$ 1,041.87	7
1010K	Nitrocharger Lift Kit Front 2"/ 0 lbs. Rear 2"/ 0 lbs	TACOMA	2016-2023	$ 1,766.87	8
1011K	Nitrocharger Lift Kit Front 2"/ 220-330lbs. Rear 2"/ 0 lbs	TACOMA	2016-2023	$ 1,766.87	8
1012K	Nitrocharger Lift Kit Front 2"/ 0 lbs. Rear 2"/ 600 lbs	TACOMA	2016-2023	$ 1,832.87	9
1013K	Nitrocharger Lift Kit Front 2"/ 220-330lbs. Rear 2"/ 600 lbs	TACOMA	2016-2023	$ 1,832.87	9
1106K	MT64 Lift Kit Front 2"/ 0lbs. Rear 0"/ 0 lbs	TACOMA	2016-2023	$ 1,854.00	10
1107K	MT64 Lift Kit Front 2"/ 220-330lbs. Rear 0"/ 0 lbs	TACOMA	2016-2023	$ 1,854.00	10
1108K	MT64 Lift Kit Front 2"/ 0lbs. Rear 2"/ 0 lbs	TACOMA	2016-2023	$ 2,764.87	10
1109K	MT64 Lift Kit Front 2"/ 220-330lbs. Rear 2"/ 0 lbs	TACOMA	2016-2023	$ 2,764.87	10
1110K	MT64 Lift Kit Front 2"/ 0lbs. Rear 2"/ 600 lbs	TACOMA	2016-2023	$ 2,830.87	11
1111K	MT64 Lift Kit Front 2"/ 220-330lbs. Rear 2"/ 600 lbs	TACOMA	2016-2023	$ 2,830.87	11
1001K	Nitrocharger Lift Kit Front 1.8"/ 0-330lbs. Rear 0"/ 0 lbs	TACOMA	1998-2004	$ 822.00	12
1002K	Nitrocharger Lift Kit Front 1.8"/ 0-330lbs. Rear 2"/ 0 lbs	TACOMA	1998-2004	$ 1,697.67	12
FJ CRUISER KITS					
4001K	Nitrocharger Lift Kit Front 2"/ 0-330lbs. Rear 0"/ 0 lbs	FJ CRUISER	2006-2017	$ 856.00	13
4002K	Nitrocharger Lift Kit Front 2"/ 0-330lbs. Rear 2"/ 0 lbs	FJ CRUISER	2006-2017	$ 1,070.00	13
4003K	Nitrocharger Lift Kit Front 2"/ 0-330lbs. Rear 2"/ 440 lbs	FJ CRUISER	2006-2017	$ 1,070.00	13
4101K	MT64 Lift Kit Front 2"/ 0-330lbs. Rear 0"/ 0 lbs	FJ CRUISER	2011-2017	$ 1,854.00	14
4102K	MT64 Lift Kit Front 2"/ 0-330lbs. Rear 2"/ 0 lbs	FJ CRUISER	2011-2017	$ 2,068.00	14
4103K	MT64 Lift Kit Front 2"/ 0-330lbs. Rear 2"/ 440 lbs	FJ CRUISER	2011-2017	$ 2,068.00	14
4201K	BP51 Lift Kit Front 2"/ 0-330lbs. Rear 0"/ 0 lbs	FJ CRUISER	2011-2017	$ 3,112.00	15
4202K	BP51 Lift Kit Front 2"/ 0-330lbs. Rear 2"/ 0 lbs	FJ CRUISER	2011-2017	$ 3,326.00	15
4203K	BP51 Lift Kit Front 2"/ 0-330lbs. Rear 2"/ 440 lbs	FJ CRUISER	2011-2017	$ 3,326.00	15
TUNDRA KITS					
3001K	Nitrocharger Lift Kit Front 2.35"/ 0-330lbs. Rear 0"/ 0 lbs	TUNDRA	2007-2021	$ 882.00	16
3002K	Nitrocharger Lift Kit Front 2.35"/ 0-330lbs. Rear 2"/ 0 lbs	TUNDRA	2007-2021	$ 1,666.58	16
3301K	BP51 Lift Kit Front 2"/ 0-330lbs. Rear 0"/ 0 lbs	TUNDRA	2007-2021	$ 3,036.00	17
3302K	BP51 Lift Kit Front 2"/ 0-330lbs. Rear 2"/ 0 lbs	TUNDRA	2007-2021	$ 3,820.58	17

4RUNNER KITS

KIT	DESC	VEHICLE	YEAR	PRICE	PAGE
2008K	Nitrocharger Lift Kit Front 2.5"/ 0lbs. Rear 0"/ 0 lbs	4RUNNER	2010-2024	$ 856.00	18
2009K	Nitrocharger Lift Kit Front 2.5"/ 220-330lbs. Rear 0"/ 0 lbs	4RUNNER	2010-2024	$ 856.00	18
2010K	Nitrocharger Lift Kit Front 2.5"/ 0lbs. Rear 2"/ 0 lbs	4RUNNER	2010-2024	$ 1,070.00	18
2011K	Nitrocharger Lift Kit Front 2.5"/ 220-330lbs. Rear 2"/ 0 lbs	4RUNNER	2010-2024	$ 1,070.00	18
2012K	Nitrocharger Lift Kit Front 2.5"/ 0lbs. Rear 2"/ 440 lbs	4RUNNER	2010-2024	$ 1,070.00	19
2013K	Nitrocharger Lift Kit Front 2.5"/ 220-330lbs. Rear 2"/ 440 lbs	4RUNNER	2010-2024	$ 1,070.00	19
2014K	Nitrocharger Lift Kit Front 2.5"/ 0lbs. Rear 2"/ 880 lbs	4RUNNER	2010-2024	$ 1,070.00	19
2015K	Nitrocharger Lift Kit Front 2.5"/ 220-330lbs. Rear 2"/ 880 lbs	4RUNNER	2010-2024	$ 1,070.00	19
2108K	MT64 Lift Kit Front 2.5"/ 0lbs. Rear 0"/ 0 lbs	4RUNNER	2003-2024	$ 1,854.00	20
2109K	MT64 Lift Kit Front 2.5"/ 220-330lbs. Rear 0"/ 0 lbs	4RUNNER	2003-2024	$ 1,854.00	20
2110K	MT64 Lift Kit Front 2.5"/ 0lbs. Rear 2"/ 0 lbs	4RUNNER	2003-2024	$ 2,068.00	20
2111K	MT64 Lift Kit Front 2.5"/ 220-330lbs. Rear 2"/ 0 lbs	4RUNNER	2003-2024	$ 2,068.00	20
2112K	MT64 Lift Kit Front 2.5"/ 0lbs. Rear 2"/ 440 lbs	4RUNNER	2003-2024	$ 2,068.00	21
2113K	MT64 Lift Kit Front 2.5"/ 220-330lbs. Rear 2"/ 440 lbs	4RUNNER	2003-2024	$ 2,068.00	21
2114K	MT64 Lift Kit Front 2.5"/ 0lbs. Rear 2"/ 880 lbs	4RUNNER	2003-2024	$ 2,068.00	21
2115K	MT64 Lift Kit Front 2.5"/ 220-330lbs. Rear 2"/ 880 lbs	4RUNNER	2003-2024	$ 2,068.00	21
2208K	BP51 Lift Kit Front 2.5"/ 0-330lbs. Rear 0"/ 0 lbs	4RUNNER	2010-2024	$ 3,112.00	22
2209K	BP51 Lift Kit Front 2.5"/ 0-330lbs. Rear 2"/ 0 lbs	4RUNNER	2010-2024	$ 3,326.00	22
2210K	BP51 Lift Kit Front 2.5"/ 0-330lbs. Rear 2"/ 440 lbs	4RUNNER	2010-2024	$ 3,326.00	22
2211K	BP51 Lift Kit Front 2.5"/ 0-330lbs. Rear 2"/ 880 lbs	4RUNNER	2010-2024	$ 3,326.00	22
2212K	BP51 Lift Kit Front 2.5"/ 0-330lbs. Rear 0"/ 0 lbs	4RUNNER	2010-2024	$ 3,069.00	23
2213K	BP51 Lift Kit Front 2.5"/ 0-330lbs. Rear 2"/ 0 lbs	4RUNNER	2010-2024	$ 3,283.00	23
2214K	BP51 Lift Kit Front 2.5"/ 0-330lbs. Rear 2"/ 440 lbs	4RUNNER	2010-2024	$ 3,283.00	23
2215K	BP51 Lift Kit Front 2.5"/ 0-330lbs. Rear 2"/ 880 lbs	4RUNNER	2010-2024	$ 3,283.00	23
2004K	Nitrocharger Lift Kit Front 1-2"/ 0-330lbs. Rear 0"/ 0 lbs	4RUNNER	2003-2010	$ 856.00	24
2005K	Nitrocharger Lift Kit Front 1-2"/ 0-330lbs. Rear 2"/ 0 lbs	4RUNNER	2003-2010	$ 1,070.00	24
2006K	Nitrocharger Lift Kit Front 1-2"/ 0-330lbs. Rear 2"/ 330 lbs	4RUNNER	2003-2010	$ 1,070.00	24
2007K	Nitrocharger Lift Kit Front 1-2"/ 0-330lbs. Rear 2"/ 660 lbs	4RUNNER	2003-2010	$ 1,070.00	24
2001K	Nitrocharger Lift Kit Front 1"/ 0-330lbs. Rear 0"/ 0 lbs	4RUNNER	1996-2002	$ 822.00	25
2002K	Nitrocharger Lift Kit Front 1"/ 0-330lbs. Rear 2"/ 0 lbs	4RUNNER	1996-2002	$ 1,036.00	25
2003K	Nitrocharger Lift Kit Front 1"/ 0-330lbs. Rear 2"/ 550 lbs	4RUNNER	1996-2002	$ 1,036.00	25

2005-2015 Toyota Tacoma
NITROCHARGER PLUS KITS

Kit Number	Price	Components	Qty	Description	Footnotes
1003K	$ 856.00	4002	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63091	2	Nitro+ Shocks (Rear)	
0-330 lbs	0 lbs	**Options**			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
Front	**Rear**	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
2"	0"	OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		FK124	2	Shock Guard Kit	Shock guard kit to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
1004K	$ 1,766.87	4002	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	EL111R	2	Multi Leaf Springs	
0-330 lbs	0 lbs	63091	2	Nitro+ Shocks (Rear)	
		OMEGP9	2	Greasable Pin Kit	
Front	**Rear**	OMEU53B	4	U Bolt	
2"	2"	OMESB108	2	Spring Bushings	
		FK29	1	Driveshaft Spacer Kit	
		Options			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
		OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		EL46XL	2	Extra Leaf 220 lbs.	Requires UCB19
		UCB19	2	Center Pin	Required when installing EL46XL
		FK124	2	Shock Guard Kit	Shock guard kit to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
1005K	$ 1,832.87	4002	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	EL112R	2	Multi Leaf Springs	
0-330 lbs	660 lbs	63091	2	Nitro+ Shocks (Rear)	
		OMEGP9	2	Greasable Pin Kit	
Front	**Rear**	OMEU53B	4	U Bolt	
2"	2"	OMESB108	2	Spring Bushings	
		FK29	1	Driveshaft Spacer Kit	
		Options			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
		OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		EL46XL	2	Extra Leaf 220 lbs.	Requires UCB4
		UCB4	2	Center Pin	Required when installing EL46XL
		FK124	2	Shock Guard Kit	Shock guard kit to protect rear shock body from stones and other external debris (x1 guard per kit)

2005-2015 Toyota Tacoma
MT64 KITS

Kit Number	Price	Components	Qty	Description	Footnotes
1103K	$ 1,854.00	4002	1	Coil Springs	See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	MT64601013L	1	MT64 Shock (Rear Left)	
0-330 lbs	0 lbs	MT64601013R	1	MT64 Shock (Rear Right)	
		Options			
Front	**Rear**	UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2"	0"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.

Kit Number	Price	Components	Qty	Description	Footnotes
1104K	$ 2,764.87	4002	1	Coil Springs	See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	EL111R	2	Multi Leaf Springs	
0-330 lbs	0 lbs	MT64601013L	1	MT64 Shock (Rear Left)	
		MT64601013R	1	MT64 Shock (Rear Right)	
Front	**Rear**	OMEGP9	2	Greasable Pin Kit	
2"	2"	OMEU53B	4	U Bolt	
		OMESB108	2	Spring Bushings	
		FK29	1	Driveshaft Spacer Kit	
		Options			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
		OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		EL46XL	2	Extra Leaf 220 lbs.	Requires UCB19
		UCB19	2	Center Pin	Required when installing EL46XL

Kit Number	Price	Components	Qty	Description	Footnotes
1105K	$ 2,830.87	4002	1	Coil Springs	See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	EL112R	2	Multi Leaf Springs	
0-330 lbs	660 lbs	MT64601014L	1	MT64 Shock (Rear Left)	
		MT64601014R	1	MT64 Shock (Rear Right)	
Front	**Rear**	OMEGP9	2	Greasable Pin Kit	
2"	2"	OMEU53B	4	U Bolt	
		OMESB108	2	Spring Bushings	
		FK29	1	Driveshaft Spacer Kit	
		Options			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
		OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		EL46XL	2	Extra Leaf 220 lbs.	Requires UCB4
		UCB4	2	Center Pin	Required when installing EL46XL

2005 - 2023 Toyota Tacoma
BP-51 KITS

Kit Number	Price	Components	Qty	Description	Footnotes
1203K	$ 3,067.00	BP5190006L	1	BP51 Coilover (Front Left)	
		BP5190006R	1	BP51 Coilover (Front Right)	
Front Load	**Rear Load**	VM80010016	1	BP51 Fit Kit (Front)	
0-330 lbs	0 lbs	BP5160011L	1	BP51 Shock (Rear Left)	
		BP5160011R	1	BP51 Shock (Rear Right)	
Front Lift	**Rear Lift**	VM80010017	1	BP51 Fit Kit (Rear)	
2"	0"	**Options**			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles

Kit Number	Price	Components	Qty	Description	Footnotes
1204K	$ 3,977.87	BP5190006L	1	BP51 Coilover (Front Left)	
		BP5190006R	1	BP51 Coilover (Front Right)	
Front Load	**Rear Load**	VM80010016	1	BP51 Fit Kit (Front)	
0-330 lbs	0 lbs	EL111R	2	Multi Leaf Springs	
		BP5160011L	1	BP51 Shock (Rear Left)	
Front Lift	**Rear Lift**	BP5160011R	1	BP51 Shock (Rear Right)	
2"	2"	VM80010017	1	BP51 Fit Kit (Rear)	
		OMEGP9	2	Greaseable Pin Kit	
		OMEU53B	4	U Bolt	
		OMESB108	2	Spring Bushings	
		FK29	1	Driveshaft Spacer Kit	
		Options			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
		EL46XL	2	Extra Leaf 220 lbs.	Requires UCB19
		UCB19	2	Centre Pin	Required when installing EL46XL

Kit Number	Price	Components	Qty	Description	Footnotes
1205K	$ 4,043.87	BP5190006L	1	BP51 Coilover (Front Left)	
		BP5190006R	1	BP51 Coilover (Front Right)	
Front Load	**Rear Load**	VM80010016	1	BP51 Fit Kit (Front)	
0-330 lbs	660 lbs	EL112R	2	Multi Leaf Springs	
		BP5160011L	1	BP51 Shock (Rear Left)	
Front Lift	**Rear Lift**	BP5160011R	1	BP51 Shock (Rear Right)	
2"	2"	VM80010017	1	BP51 Fit Kit (Rear)	
		OMEGP9	2	Greaseable Pin Kit	
		OMEU53B	4	U Bolt	
		OMESB108	2	Spring Bushings	
		FK29	1	Driveshaft Spacer Kit	
		Options			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
		EL46XL	2	Extra Leaf 220 lbs.	Requires UCB19
		UCB19	2	Centre Pin	Required when installing EL46XL

2016 - 2023 Toyota Tacoma
NITROCHARGER PLUS KITS: PAGE 1/3

Kit Number	Price	Components	Qty	Description	Footnotes
1006K	$ 856.00	4007	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63091	2	Nitro+ Shocks (Rear)	
0 lbs	0 lbs	**Options**			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
Front Lift	**Rear Lift**	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
2"	0"	OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		FK124	2	Shock Guard Kit	Shock guard kit to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
1007K	$ 856.00	4004	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63091	2	Nitro+ Shocks (Rear)	
220-330 lbs	0 lbs	**Options**			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
Front Lift	**Rear Lift**	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
2"	0"	OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		FK124	2	Shock Guard Kit	Shock guard kit to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
1008K	$ 1,041.87	4007	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63091	2	Nitro+ Shocks (Rear)	
0 lbs	0 lbs	3460023	1	Spacer block kit (Rear)	
		OMEU53B	4	U Bolt	
Front Lift	**Rear Lift**	FK29	1	Driveshaft Spacer	
2"	1.25"	**Options**			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
		OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		FK124	2	Shock Guard Kit	Shock guard kit to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
1009K	$ 1,041.87	4004	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63091	2	Nitro+ Shocks (Rear)	
220-330 lbs	0 lbs	3460023	1	Spacer block kit (Rear)	
		OMEU53B	4	U Bolt	
Front Lift	**Rear Lift**	FK29	1	Driveshaft Spacer	
2"	1.25"	**Options**			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
		OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		FK124	2	Shock Guard Kit	Shock guard kit to protect rear shock body from stones and other external debris (x1 guard per kit)

2016 - 2023 Toyota Tacoma
NITROCHARGER PLUS KITS: PAGE 2/3

Kit Number	Price	Components	Qty	Description	Footnotes
1010K	$ 1,766.87	4007	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	EL111R	2	Multi Leaf Springs	
0 lbs	0 lbs	63091	2	Nitro+ Shocks (Rear)	
		OMEGP9	2	Greaseable Pin Kit	
Front Lift	**Rear Lift**	OMEU53B	4	U Bolt	
2"	2"	OMESB108	2	Spring Bushings	
		FK29	1	Driveshaft Spacer Kit	
		Options			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
		OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		EL46XL	2	Extra Leaf 220 lbs.	Requires UCB19
		UCB19	2	Centre Pin	Required when installing EL46XL
		FK124	2	Shock Guard Kit	Shock guard kit to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
1011K	$ 1,766.87	4004	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	EL111R	2	Multi Leaf Springs	
220-330 lbs	0 lbs	63091	2	Nitro+ Shocks (Rear)	
		OMEGP9	2	Greaseable Pin Kit	
Front Lift	**Rear Lift**	OMEU53B	4	U Bolt	
2"	2"	OMESB108	2	Spring Bushings	
		FK29	1	Driveshaft Spacer Kit	
		Options			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
		OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		EL46XL	2	Extra Leaf 220 lbs.	Requires UCB19
		UCB19	2	Centre Pin	Required when installing EL46XL
		FK124	2	Shock Guard Kit	Shock guard kit to protect rear shock body from stones and other external debris (x1 guard per kit)

2016 - 2023 Toyota Tacoma
NITROCHARGER PLUS KITS: PAGE 3/3

Kit Number	Price	Components	Qty	Description	Footnotes
1012K	$ 1,832.87	4007	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	EL112R	2	Multi Leaf Springs	
0 lbs	600 lbs	63091	2	Nitro+ Shocks (Rear)	
		OMEGP9	2	Greaseable Pin Kit	
Front Lift	**Rear Lift**	OMEU53B	4	U Bolt	
2"	2"	OMESB108	2	Spring Bushings	
		FK29	1	Driveshaft Spacer Kit	
		Options			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
		OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		EL46XL	2	Extra Leaf 220 lbs.	Requires UCB4
		UCB4	2	Centre Pin	Required when installing EL46XL
		FK124	2	Shock Guard Kit	Shock guard kit to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
1013K	$ 1,832.87	4004	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	EL112R	2	Multi Leaf Springs	
220-330 lbs	600 lbs	63091	2	Nitro+ Shocks (Rear)	
		OMEGP9	2	Greaseable Pin Kit	
Front Lift	**Rear Lift**	OMEU53B	4	U Bolt	
2"	2"	OMESB108	2	Spring Bushings	
		FK29	1	Driveshaft Spacer Kit	
		Options			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
		OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		EL46XL	2	Extra Leaf 220 lbs.	Requires UCB4
		UCB4	2	Centre Pin	Required when installing EL46XL
		FK124	2	Shock Guard Kit	Shock guard kit to protect rear shock body from stones and other external debris (x1 guard per kit)

2016 - 2023 Toyota Tacoma - MT64 KITS: PAGE 1/2

Kit Number	Price	Components	Qty	Description	Footnotes
1106K	$ 1,854.00	4007	1	Coil Springs	Install coil in tallest position. See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	MT64601013L	1	MT64 Shock (Rear Left)	
0 lbs	0 lbs	MT64601013R	1	MT64 Shock (Rear Right)	
		Options			
Front Lift	**Rear Lift**	UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2"	0"	OME3133	2	Upper Strut Bushings	No top mounting bushes supplied, use OME3133. OE bushes may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.

Kit Number	Price	Components	Qty	Description	Footnotes
1107K	$ 1,854.00	4004	1	Coil Springs	Install coil in tallest position. See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	MT64601013L	1	MT64 Shock (Rear Left)	
220-330 lbs	0 lbs	MT64601013R	1	MT64 Shock (Rear Right)	
		Options			
Front Lift	**Rear Lift**	UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2"	0"	OME3133	2	Upper Strut Bushings	No top mounting bushes supplied, use OME3133. OE bushes may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.

Kit Number	Price	Components	Qty	Description	Footnotes
1108K	$ 2,764.87	4007	1	Coil Springs	Install coil in tallest position. See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	EL111R	2	Multi Leaf Springs	
0 lbs	0 lbs	MT64601013L	1	MT64 Shock (Rear Left)	
		MT64601013R	1	MT64 Shock (Rear Right)	
Front Lift	**Rear Lift**	OMEGP9	2	Greaseable Pin Kit	
2"	2"	OMEU53B	4	U Bolt	
		OMESB108	2	Spring Bushings	
		FK29	1	Driveshaft Spacer Kit	
		Options			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
		OME3133	2	Upper Strut Bushings	No top mounting bushes supplied, use OME3133. OE bushes may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		EL46XL	2	Extra Leaf 220 lbs.	Requires UCB19
		UCB19	2	Centre Pin	Required when installing EL46XL

Kit Number	Price	Components	Qty	Description	Footnotes
1109K	$ 2,764.87	4004	1	Coil Springs	Install coil in tallest position. See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	EL111R	2	Multi Leaf Springs	
220-330 lbs	0 lbs	MT64601013L	1	MT64 Shock (Rear Left)	
		MT64601013R	1	MT64 Shock (Rear Right)	
Front Lift	**Rear Lift**	OMEGP9	2	Greaseable Pin Kit	
2"	2"	OMEU53B	4	U Bolt	
		OMESB108	2	Spring Bushings	
		FK29	1	Driveshaft Spacer Kit	
		Options			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
		OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		EL46XL	2	Extra Leaf 220 lbs.	Requires UCB19
		UCB19	2	Centre Pin	Required when installing EL46XL

2016 - 2023 Toyota Tacoma
MT64 KITS: PAGE 2/2

Kit Number	Price	Components	Qty	Description	Footnotes
1110K	$ 2,830.87	4007	1	Coil Springs	Install coil in tallest position. See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	EL112R	2	Multi Leaf Springs	
0 lbs	600 lbs	MT64601014L	1	MT64 Shock (Rear Left)	
		MT64601014R	1	MT64 Shock (Rear Right)	
Front Lift	**Rear Lift**	OMEGP9	2	Greaseable Pin Kit	
2"	2"	OMEU53B	4	U Bolt	
		OMESB108	2	Spring Bushings	
		FK29	1	Driveshaft Spacer Kit	
		Options			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
		OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		EL46XL	2	Extra Leaf 220 lbs.	Requires UCB19
		UCB19	2	Centre Pin	Required when installing EL46XL

Kit Number	Price	Components	Qty	Description	Footnotes
1111K	$ 2,830.87	4004	1	Coil Springs	Install coil in tallest position. See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	EL112R	2	Multi Leaf Springs	
220-330 lbs	600 lbs	MT64601014L	1	MT64 Shock (Rear Left)	
		MT64601014R	1	MT64 Shock (Rear Right)	
Front Lift	**Rear Lift**	OMEGP9	2	Greaseable Pin Kit	
2"	2"	OMEU53B	4	U Bolt	
		OMESB108	2	Spring Bushings	
		FK29	1	Driveshaft Spacer Kit	
		Options			
		UCA0005	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
		OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		EL46XL	2	Extra Leaf 220 lbs.	Requires UCB4
		UCB4	2	Centre Pin	Required when installing EL46XL

1998-2004 Toyota Tacoma
NITROCHARGER PLUS KITS

Kit Number	Price	Components	Qty	Description	Footnotes
1001K	$ 822.00	4006	1	Coil Springs	
		93004	2	Nitro+ Shocks (Front)	
Front Load	**Rear Load**	63062	2	Nitro+ Shocks (Rear)	
0-330 lbs	0 lbs	**Options**			
		FK124	2	Shock Guard Kit	Shock guard kit to protect rear shock body from stones and other external debris (x1 guard per kit)
Front	**Rear**				
1.8"	0"				

Kit Number	Price	Components	Qty	Description	Footnotes
1002K	$ 1,697.67	4006	1	Coil Springs	
		93004	2	Nitro+ Shocks (Front)	
Front Load	**Rear Load**	EL122RA	1	Multi Leaf Spring	
0-330 lbs	0 lbs	EL122RB	1	Multi Leaf Spring	
		63065	2	Nitro+ Shocks (Rear)	
Front	**Rear**	OMEGS12	2	Greasable Shackle Kit	
1.8"	2"	OMEU53A	4	U Bolt	
		OMESB121	2	Spring Bushings	
		FK21	1	Exhaust Bracket Kit	
		Options			
		D43XL	2	Extra Leaf 220 lbs.	Requires UCB19
		UCB19	2	Center Pin	Required when installing D43XL
		FK124	2	Shock Guard Kit	Shock guard kit to protect rear shock body from stones and other external debris (x1 guard per kit)

2007-2014 FJ Cruiser
NITROCHARGER PLUS KITS

Kit Number	Price	Components	Qty	Description	Footnotes
4001K	$ 856.00	4007	1	Coil Springs	See shock absorber installation instructions for various lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63112	2	Nitro+ Shocks (Rear)	
0-330 lbs	0 lbs	**Options**			
		UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
Front	**Rear**	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
2"	0"	OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		FK124	2	Shock Guard Kit	Shock guard kit to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
4002K	$ 1,070.00	4007	1	Coil Springs	See shock absorber installation instructions for various lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63112	2	Nitro+ Shocks (Rear)	
0-330 lbs	0 lbs	2895E	1	Coil Springs	
		Options			
Front	**Rear**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		FK124	2	Shock Guard Kit	Shock guard kit to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
4003K	$ 1,070.00	4007	1	Coil Springs	See shock absorber installation instructions for various lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63081	2	Nitro+ Shocks (Rear)	
0-330 lbs	440 lbs	2896	1	Coil Springs	
		Options			
Front	**Rear**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		FK124	2	Shock Guard Kit	Shock guard kit recommended to protect rear shock body from stones and other external debris (x1 guard per kit)

2010-2014 FJ CRUISER
MT64 KITS

Kit Number	Price	Components	Qty	Description	Footnotes
4101K	$ 1,854.00	4007	1	Coil Springs	See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	MT64601011	2	MT64 Shocks (Rear)	
0-330 lbs	0 lbs	**Options**			
		UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
Front Lift	**Rear Lift**	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
2"	0"	OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.

Kit Number	Price	Components	Qty	Description	Footnotes
4102K	$ 2,068.00	4007	1	Coil Springs	See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	MT64601011	2	MT64 Shocks (Rear)	
0-330 lbs	0 lbs	2895E	1	Coil Springs	
		Options			
Front Lift	**Rear Lift**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.

Kit Number	Price	Components	Qty	Description	Footnotes
4103K	$ 2,068.00	4007	1	Coil Springs	See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	MT64601009	2	MT64 Shocks (Rear)	
0-330 lbs	440 lbs	2896	1	Coil Springs	
		Options			
Front Lift	**Rear Lift**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.

2011-2017 FJ CRUISER
BP-51 KITS

Kit Number	Price	Components	Qty	Description	Footnotes
4201K	$ 3,112.00	BP5190002L	1	BP51 Coilover (Front Left)	
		BP5190002R	1	BP51 Coilover (Front Right)	
Front Load	**Rear Load**	VM80010028	1	BP51 Fit Kit (Front)	
0-330 lbs	0 lbs	BP5160025	2	BP51 Shock (Rear)	
		VM80010010	1	BP51 Fit Kit (Rear)	
Front Lift	**Rear Lift**	**Options**			
2"	0"	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles

Kit Number	Price	Components	Qty	Description	Footnotes
4202K	$ 3,326.00	BP5190002L	1	BP51 Coilover (Front Left)	
		BP5190002R	1	BP51 Coilover (Front Right)	
Front Load	**Rear Load**	VM80010028	1	BP51 Fit Kit (Front)	
0-330 lbs	0 lbs	2895E	1	Coil Spring (Rear)	
		BP5160025	2	BP51 Shock (Rear)	
Front Lift	**Rear Lift**	VM80010010	1	BP51 Fit Kit (Rear)	
2"	2"	**Options**			
		UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles

Kit Number	Price	Components	Qty	Description	Footnotes
4203K	$ 3,326.00	BP5190002L	1	BP51 Coilover (Front Left)	
		BP5190002R	1	BP51 Coilover (Front Right)	
Front Load	**Rear Load**	VM80010028	1	BP51 Fit Kit (Front)	
0-330 lbs	440 lbs	2896	1	Coil Spring (Rear)	
		BP5160025	2	BP51 Shock (Rear)	
Front Lift	**Rear Lift**	VM80010010	1	BP51 Fit Kit (Rear)	
2"	2"	**Options**			
		UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles

2007-2021 Toyota Tundra
NITROCHARGER PLUS KITS

Kit Number	Price	Components	Qty	Description	Footnotes	Footnotes
3001K	$ 882.00	4017	1	Coil Springs	See shock absorber installation instructions for various lift height settings.	
		93018	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.	
Front Load	**Rear Load**	63100	2	Nitro+ Shocks (Rear)		
0-330 lbs	0 lbs	**Options**				
		N/A				
Front	**Rear**					
2.35"	0"					

Kit Number	Price	Components	Qty	Description	Footnotes	Footnotes
3002K	$ 1,666.58	4017	1	Coil Springs	See shock absorber installation instructions for various lift height settings.	
		93018	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.	
Front Load	**Rear Load**	CS055R	2	Multi Leaf Springs	Models with rear sway bar will require end link modifications to retain sway bar in operation.	CS055R is supplied with bushes installed.
0-330 lbs	0 lbs	63100	2	Nitro+ Shocks (Rear)		
		OMEU53B	4	U Bolt		
Front	**Rear**	FK32	1	Breakline Kit	Mandatory fit	
2.35"	2"	**Options**				
		OMEGS22	2	Greasable Shackle Kit	Requires OMESB106	
		D28XL	2	Extra Leaf 220 lbs.		
		OMESB106	2	Spring Bushings	Only required if fitting OMEGS22	

2007-2021 Toyota Tundra
BP-51 KITS

Kit Number	Price	Components	Qty	Description	Footnotes	Footnotes
3201K	$ 3,036.00	BP5190010L	1	BP51 Coilover (Front Left)		
		BP5190010R	1	BP51 Coilover (Front Right)		
Front Load	**Rear Load**	VM80010034	1	BP51 Fit Kit (Front)		
0-330 lbs	0 lbs	BP5160020L	1	BP51 Shock (Rear Left)		
		BP5160020R	1	BP51 Shock (Rear Right)		
Front	**Rear**	VM80010035	1	BP51 Fit Kit (Rear)		
2"	0"	**Options**				
		N/A				

Kit Number	Price	Components	Qty	Description	Footnotes	Footnotes
3202K	$ 3,820.58	BP5190010L	1	BP51 Coilover (Front Left)		
		BP5190010R	1	BP51 Coilover (Front Right)		
Front Load	**Rear Load**	VM80010034	1	BP51 Fit Kit (Front)		
0-330 lbs	0 lbs	CS055R	2	Multi Leaf Springs	Models with rear sway bar will require end link modifications to retain sway bar in operation.	CS055R is supplied with bushes installed.
		BP5160020L	1	BP51 Shock (Rear Left)		
Front	**Rear**	BP5160020R	1	BP51 Shock (Rear Right)		
2"	2"	VM80010035	1	BP51 Fit Kit (Rear)		
		OMEU53B	4	U Bolt		
		FK32	1	Breakline Kit	Mandatory fit	
		Options				
		OMEGS22	2	Greasable Shackle Kit	Requires OMESB106	
		D28XL	2	Extra Leaf 220 lbs.		
		OMESB106	2	Spring Bushings	Only required if fitting OMEGS22	

2010-2024 4Runner: PAGE 1/2
NITROCHARGER PLUS KITS

Kit Number	Price	Components	Qty	Description	Footnotes
2008K	$ 856.00	4026	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93010	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63080	2	Nitro+ Shocks (Rear)	
0 lbs	0 lbs	**Options**			
		UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
Front Lift	**Rear Lift**	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
2.5"	0"	OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		FK124	2	Shock Guard Kit	Shock guard kit recommended to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
2009K	$ 856.00	4007	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93010	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63080	2	Nitro+ Shocks (Rear)	
220-330 lbs	0 lbs	**Options**			
		UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
Front Lift	**Rear Lift**	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
2.5"	0"	OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		FK124	2	Shock Guard Kit	Shock guard kit recommended to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
2010K	$ 1,070.00	4026	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93010	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63080	2	Nitro+ Shocks (Rear)	
0 lbs	0 lbs	2895	1	Coil Springs	
		Options			
Front Lift	**Rear Lift**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2.5"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		OME150PR10	1	Trim Packer (Rear)	For side to side trim where required (Rear)
		FK124	2	Shock Guard Kit	Shock guard kit recommended to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
2011K	$ 1,070.00	4007	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93010	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63080	2	Nitro+ Shocks (Rear)	
220-330 lbs	0 lbs	2895	1	Coil Springs	
		Options			
Front Lift	**Rear Lift**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2.5"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		OME150PR10	1	Trim Packer (Rear)	For side to side trim where required (Rear)
		FK124	2	Shock Guard Kit	Shock guard kit recommended to protect rear shock body from stones and other external debris (x1 guard per kit)

2010-2024 4Runner: PAGE 2/2
NITROCHARGER PLUS KITS

Kit Number	Price	Components	Qty	Description	Footnotes
2012K	$ 1,070.00	4026	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93010	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63081	2	Nitro+ Shocks (Rear)	
0 lbs	440 lbs	2896	1	Coil Springs	
		Options			
Front Lift	**Rear Lift**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2.5"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		OME150PR10	1	Trim Packer (Rear)	For side to side trim where required (Rear)
		FK124	2	Shock Guard Kit	Shock guard kit recommended to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
2013K	$ 1,070.00	4007	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93010	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63081	2	Nitro+ Shocks (Rear)	
220-330 lbs	440 lbs	2896	1	Coil Springs	
		Options			
Front Lift	**Rear Lift**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2.5"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		OME150PR10	1	Trim Packer (Rear)	For side to side trim where required (Rear)
		FK124	2	Shock Guard Kit	Shock guard kit recommended to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
2014K	$ 1,070.00	4026	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93010	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63081	2	Nitro+ Shocks (Rear)	
0 lbs	880 lbs	2897	1	Coil Springs	
		Options			
Front Lift	**Rear Lift**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2.5"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		OME150PR10	1	Trim Packer (Rear)	For side to side trim where required (Rear)
		FK124	2	Shock Guard Kit	Shock guard kit recommended to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
2015K	$ 1,070.00	4007	1	Coil Springs	Install using largest spacer in the tallest orientation. See shock absorber installation instructions for additional lift height settings.
		93010	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63081	2	Nitro+ Shocks (Rear)	
220-330lbs	880 lbs	2897	1	Coil Springs	
		Options			
Front Lift	**Rear Lift**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2.5"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		OME150PR10	1	Trim Packer (Rear)	For side to side trim where required (Rear)
		FK124	2	Shock Guard Kit	Shock guard kit recommended to protect rear shock body from stones and other external debris (x1 guard per kit)

2003-2024 4Runner
MT64 KITS: PAGE 1/2

Kit Number	Price	Components	Qty	Description	Footnotes
2108K	$ 1,854.00	4026	1	Coil Springs	Install coil in tallest position. See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils
Front Load	**Rear Load**	MT64601009	2	MT64 Shocks (Rear)	
0 lbs	0 lbs	**Options**			
		UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
Front Lift	**Rear Lift**	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
2.5"	0"	OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.

Kit Number	Price	Components	Qty	Description	Footnotes
2109K	$ 1,854.00	4007	1	Coil Springs	Install coil in tallest position. See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils
Front Load	**Rear Load**	MT64601009	2	MT64 Shocks (Rear)	
220-330 lbs	0 lbs	**Options**			
		UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
Front Lift	**Rear Lift**	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
2.5"	0"	OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.

Kit Number	Price	Components	Qty	Description	Footnotes
2110K	$ 2,068.00	4026	1	Coil Springs	Install coil in tallest position. See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils
Front Load	**Rear Load**	MT64601009	2	MT64 Shocks (Rear)	
0 lbs	0 lbs	2895	1	Coil Springs	
		Options			
Front Lift	**Rear Lift**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2.5"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		OME150PR10	1	Trim Packer (Rear)	For side to side trim where required (Rear)

Kit Number	Price	Components	Qty	Description	Footnotes
2111K	$ 2,068.00	4007	1	Coil Springs	Install coil in tallest position. See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils
Front Load	**Rear Load**	MT64601009	2	MT64 Shocks (Rear)	
220-330 lbs	0 lbs	2895	1	Coil Springs	
		Options			
Front Lift	**Rear Lift**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2.5"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		OME150PR10	1	Trim Packer (Rear)	For side to side trim where required (Rear)

2003-2024 4Runner
MT64 KITS: PAGE 2/2

Kit Number	Price	Components	Qty	Description	Footnotes
2112K	$ 2,068.00	4026	1	Coil Springs	Install coil in tallest position. See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils
Front Load	**Rear Load**	MT64601009	2	MT64 Shocks (Rear)	
0 lbs	440 lbs	2896	1	Coil Springs	
		Options			
Front Lift	**Rear Lift**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2.5"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		OME150PR10	1	Trim Packer (Rear)	For side to side trim where required (Rear)

Kit Number	Price	Components	Qty	Description	Footnotes
2113K	$ 2,068.00	4007	1	Coil Springs	Install coil in tallest position. See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils
Front Load	**Rear Load**	MT64601009	2	MT64 Shocks (Rear)	
220-330 lbs	440 lbs	2896	1	Coil Springs	
		Options			
Front Lift	**Rear Lift**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2.5"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		OME150PR10	1	Trim Packer (Rear)	For side to side trim where required (Rear)

Kit Number	Price	Components	Qty	Description	Footnotes
2114K	$ 2,068.00	4026	1	Coil Springs	Install coil in tallest position. See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils
Front Load	**Rear Load**	MT64601010	2	MT64 Shocks (Rear)	
0 lbs	880 lbs	2897	1	Coil Springs	
		Options			
Front Lift	**Rear Lift**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2.5"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		OME150PR10	1	Trim Packer (Rear)	For side to side trim where required (Rear)

Kit Number	Price	Components	Qty	Description	Footnotes
2115K	$ 2,068.00	4007	1	Coil Springs	Install coil in tallest position. See shock absorber installation instructions for various lift height settings.
		MT64901007	2	MT64 Shocks (Front)	Does Not Suit OE Coils
Front Load	**Rear Load**	MT64601010	2	MT64 Shocks (Rear)	
220-330 lbs	880 lbs	2897	1	Coil Springs	
		Options			
Front Lift	**Rear Lift**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
2.5"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		OME150PR10	1	Trim Packer (Rear)	For side to side trim where required (Rear)

2010-2024 4Runner NON-KDSS
BP-51 KITS

Kit Number	Price	Components	Qty	Description	Footnotes
2208K	$ 3,112.00	BP5190002L	1	BP51 Coilover (Front Left)	
		BP5190002R	1	BP51 Coilover (Front Right)	
Front Load	**Rear Load**	VM80010028	1	BP51 Fit Kit (Front)	
0-330 lbs	0 lbs	BP5160025	2	BP51 Shock (Rear)	
		VM80010010	1	BP51 Fit Kit (Rear)	
Front Lift	**Rear Lift**	**Options**			
2.5"	0"	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles

Kit Number	Price	Components	Qty	Description	Footnotes
2209K	$ 3,326.00	BP5190002L	1	BP51 Coilover (Front Left)	
		BP5190002R	1	BP51 Coilover (Front Right)	
Front Load	**Rear Load**	VM80010028	1	BP51 Fit Kit (Front)	
0-330 lbs	0 lbs	2895	1	Coil Spring (Rear)	
		BP5160025	2	BP51 Shock (Rear)	
Front Lift	**Rear Lift**	VM80010010	1	BP51 Fit Kit (Rear)	
2.5"	2"	**Options**			
		UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles

Kit Number	Price	Components	Qty	Description	Footnotes
2210K	$ 3,326.00	BP5190002L	1	BP51 Coilover (Front Left)	
		BP5190002R	1	BP51 Coilover (Front Right)	
Front Load	**Rear Load**	VM80010028	1	BP51 Fit Kit (Front)	
0-330 lbs	440 lbs	2896	1	Coil Spring (Rear)	
		BP5160025	2	BP51 Shock (Rear)	
Front Lift	**Rear Lift**	VM80010010	1	BP51 Fit Kit (Rear)	
2.5"	2"	**Options**			
		UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles

Kit Number	Price	Components	Qty	Description	Footnotes
2211K	$ 3,326.00	BP5190002L	1	BP51 Coilover (Front Left)	
		BP5190002R	1	BP51 Coilover (Front Right)	
Front Load	**Rear Load**	VM80010028	1	BP51 Fit Kit (Front)	
0-330 lbs	880 lbs	2897	1	Coil Spring (Rear)	
		BP5160025	2	BP51 Shock (Rear)	
Front Lift	**Rear Lift**	VM80010010	1	BP51 Fit Kit (Rear)	
2.5"	2"	**Options**			
		UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles

2010-2024 4Runner WITH KDSS
BP-51KITS

Kit Number	Price	Components	Qty	Description	Footnotes
2212K	$ 3,069.00	BP5190004L	1	BP51 Coilover (Front Left)	
		BP5190002R	1	BP51 Coilover (Front Right)	
Front Load	**Rear Load**	VM80010009	1	BP51 Fit Kit (Front)	
0-330 lbs	0 lbs	BP5160025	2	BP51 Shock (Rear)	
		VM80010010	1	BP51 Fit Kit (Rear)	
Front Lift	**Rear Lift**	**Options**			
2.5"	0"	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles

Kit Number	Price	Components	Qty	Description	Footnotes
2213K	$ 3,283.00	BP5190004L	1	BP51 Coilover (Front Left)	
		BP5190002R	1	BP51 Coilover (Front Right)	
Front Load	**Rear Load**	VM80010009	1	BP51 Fit Kit (Front)	
0-330 lbs	0 lbs	2895	1	Coil Spring (Rear)	
		BP5160025	2	BP51 Shock (Rear)	
Front Lift	**Rear Lift**	VM80010010	1	BP51 Fit Kit (Rear)	
2.5"	2"	**Options**			
		UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles

Kit Number	Price	Components	Qty	Description	Footnotes
2214K	$ 3,283.00	BP5190004L	1	BP51 Coilover (Front Left)	
		BP5190002R	1	BP51 Coilover (Front Right)	
Front Load	**Rear Load**	VM80010009	1	BP51 Fit Kit (Front)	
0-330 lbs	440 lbs	2896	1	Coil Spring (Rear)	
		BP5160025	2	BP51 Shock (Rear)	
Front Lift	**Rear Lift**	VM80010010	1	BP51 Fit Kit (Rear)	
2.5"	2"	**Options**			
		UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles

Kit Number	Price	Components	Qty	Description	Footnotes
2215K	$ 3,283.00	BP5190004L	1	BP51 Coilover (Front Left)	
		BP5190002R	1	BP51 Coilover (Front Right)	
Front Load	**Rear Load**	VM80010009	1	BP51 Fit Kit (Front)	
0-330 lbs	880 lbs	2897	1	Coil Spring (Rear)	
		BP5160025	2	BP51 Shock (Rear)	
Front Lift	**Rear Lift**	VM80010010	1	BP51 Fit Kit (Rear)	
2.5"	2"	**Options**			
		UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles

2003-2010 4Runner
NITROCHARGER PLUS KITS

Kit Number	Price	Components	Qty	Description	Footnotes
2004K	$ 856.00	4001	1	Coil Springs	See shock absorber installation instructions for various lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63004	2	Nitro+ Shocks (Rear)	
0-330 lbs	0 lbs	**Options**			
		UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
Front Lift	**Rear Lift**	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
1-2"	0"	OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		FK124	2	Shock Guard Kit	Shock guard kit recommended to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
2005K	$ 1,070.00	4001	1	Coil Springs	See shock absorber installation instructions for various lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	2895	1	Coil Springs	
0-330 lbs	0 lbs	63004	2	Nitro+ Shocks (Rear)	
		Options			
Front Lift	**Rear Lift**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
1-2"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		FK124	2	Shock Guard Kit	Shock guard kit recommended to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
2006K	$ 1,070.00	4001	1	Coil Springs	See shock absorber installation instructions for various lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	2896	1	Coil Springs	
0-330 lbs	330 lbs	63005	2	Nitro+ Shocks (Rear)	
		Options			
Front Lift	**Rear Lift**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
1-2"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		FK124	2	Shock Guard Kit	Shock guard kit recommended to protect rear shock body from stones and other external debris (x1 guard per kit)

Kit Number	Price	Components	Qty	Description	Footnotes
2007K	$ 1,070.00	4001	1	Coil Springs	See shock absorber installation instructions for various lift height settings.
		93000	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	2897	1	Coil Springs	
0-330 lbs	660 lbs	63005	2	Nitro+ Shocks (Rear)	
		Options			
Front Lift	**Rear Lift**	UCA0004	1	Upper Control Arm	UCA recommended to achieve factory alignment spec's & should be performed by a mechanic experienced in ride-height adjusted vehicles
1-2"	2"	OME3133	2	Upper Strut Bushings	No top mounting bushings supplied, use OME3133. OE bushings may be re-used if in good condition.
		OMETH002	2	Strut Top Hat	Strut Top Hat Kit may be required if original equipment is worn.
		FK124	2	Shock Guard Kit	Shock guard kit recommended to protect rear shock body from stones and other external debris (x1 guard per kit)

1996-2002 4Runner/Surf
NITROCHARGER PLUS KITS

Kit Number	Price	Components	Qty	Description	Footnotes
2001K	$ 822.00	4006	1	Coil Springs	See shock absorber installation instructions for various lift height settings.
		93004	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	63028	2	Nitro+ Shocks (Rear)	
0-330 lbs	0 lbs	**Options**			
		FK124	2	Shock Guard Kit	Shock guard kit recommended to protect rear shock body from stones and other external debris (x1 guard per kit)
Front	**Rear**				
1"	0"				

Kit Number	Price	Components	Qty	Description	Footnotes
2002K	$ 1,036.00	4006	1	Coil Springs	See shock absorber installation instructions for various lift height settings.
		93004	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	2906	1	Coil Springs	
0-330 lbs	0 lbs	63028	2	Nitro+ Shocks (Rear)	
		Options			
Front	**Rear**	FK124	2	Shock Guard Kit	Shock guard kit recommended to protect rear shock body from stones and other external debris (x1 guard per kit)
1"	2"				

Kit Number	Price	Components	Qty	Description	Footnotes
2003K	$ 1,036.00	4006	1	Coil Springs	See shock absorber installation instructions for various lift height settings.
		93004	2	Nitro+ Shocks (Front)	Does Not Suit OE Coils.
Front Load	**Rear Load**	2890	1	Coil Springs	
0-330 lbs	550 lbs	63027	2	Nitro+ Shocks (Rear)	
		Options			
Front	**Rear**	FK124	2	Shock Guard Kit	Shock guard kit recommended to protect rear shock body from stones and other external debris (x1 guard per kit)
1"	2"				